

vCam Wi-Fi Adapter (WFA) Quick Setup and Connect Guide V1.0



-  Power on/off
-  Wi-Fi Status indicator
-  Battery status indicator
-  Charge for three hour to a full charge
-  USB-C AC/DC Charging socket
-  USB-A socket

Step 1

Scan the QR code to download the vCam Mobile Controller (VMC) App.



Or




Step 2

Select vCam Wi-Fi Adapter (WFA) to enter the vCam Wi-Fi Adapter application.



Step 3

Select the vCam Wi-Fi Adapter WLAN network connect to vCam Wi-Fi Adapter.




Step 4

When connected select **Settings** to enter the settings menu.



Step 5

Select **Reel Settings**.



Step 6

Select the **Reel type** with its length.



Step 7

Tap the Settings  icon to return to the main viewing screen.

 Tap the Help icon  in the vCam Mobile Controller app for detailed instructions.



vCam Mobile Controller App

Vivax-Metrotech Corporation (Headquarters)

3251 Olcott Street, Santa Clara, CA 95054, USA

T/Free: 1-800-446-3392

Tel: +1-408-734-3880

Fax: +1-408-904-4964

Email: SalesUSA@vxmt.com

Website: www.vivax-metrotech.com

Visit us at www.vivax-metrotech.com to view our full product line and worldwide locations.